

CARE & MAINTENANCE

BELLA SERIES PORCELAIN PANELS

THE CARE AND MAINTENANCE WILL HELP YOU KEEP YOUR BELLA SERIES SURFACE IN PRISTINE CONDITION FOR YEARS TO COME.

Bella Series porcelain panels are easy to clean and maintain. Regular cleaning highlights the aesthetic features of the material and gives the product an exceptional shine. Thanks to the characteristics of the production process (high firing temperature, raw materials of great quality, sinterizing process), the surface of Bella Series material is also waterproof (the water absorption is minimal).

The term "cleanability" means the ability of a material to permit the removal of dirt and dust settled on the surface in order to guarantee the required hygienic conditions. As this feature is tightly linked with the surface compactness and impermeability and with the material's resistance to chemical agents, Bella Series products offer outstanding cleanability.

1 ROUTINE CARE & MAINTENANCE

For routine cleaning, use small quantities of non-bleach, non-abrasive cleaners together with warm water and a damp cloth or sponge. Liquid spills including fruits, vegetables, food colourings and curries should be wiped up and cleaned with a mild detergent and water immediately after detection.

2 PREVENTING HEAT DAMAGE

Protective trivets and heat pads must always be used underneath cookware such as skillets, saucepans, pots or dishes when removing hot items directly from any heat source (oven cooktop or microwave) and placing onto the Bella Series surface. Prolonged or sudden extreme temperature changes can permanently damage the material which is not covered under warranty.

3 PREVENTING SCRATCHES

The use of cutting boards and taking care not to drop or move heavy objects on the surface will help to ensure the long-lasting beauty of Bella Series. The Bella Series resilient surface has been designed to withstand normal daily use and whilst it is resistant to scratches, cuts and chipping, cutting directly on the Bella Series should be avoided.

4 CHEMICALS

There are some strong chemicals and solvents that can cause damage to the Bella Series. Paint remover, paint and stain strippers, nail polish removers, bleach, furniture cleaners, oil soaps, permanent markers or inks, oven cleaners, drain cleaners and chemicals with high alkaline pH levels are examples of products that could damage the surface. If a strong chemical or solvent comes into contact with your Bella Series surface, rinse immediately with plenty of water then follow with normal cleaning procedures.

5 REMOVING DIFFICULT SPILLS

If normal cleaning procedures do not work on stubborn or dried spills, use a non-abrasive cleaning pad such as a household sponge, along with a common mild cream cleanser or a glass and surface cleaner. Gently scrape off the substance, then follow the routine cleaning procedures listed above.

6 GENERAL COMMENTS

Bella Series requires no sealing or special cleaning products.